

INSTALLATION INSTRUCTIONS

⚠ WARNING: DO NOT EXCEED PRODUCT RATING OR TOW VEHICLE LAMP LOAD RATING, WHICHEVER IS LOWER

56325 APPLICATIONS

Make	Model
Cadillac	XT5
GMC	Acadia (excluding Limited)

WIRING LOCATION GUIDE


SUVs, MINI & FULL-SIZED VANS (S)

Representative vehicle shown below

S6 - Behind center of rear bumper



CUSTOM WIRING CONNECTOR



NOTICE

All steps must be followed to ensure the CURT wiring connector will function properly. Once installed, test for proper function by using a test light or connecting a properly wired trailer.

All connections must be complete for the wiring harness to function. Test and verify installation of product with test light or trailer after installation. For initial test, reset electrical system of the vehicle by temporarily removing the vehicle's key from the ignition.

TOOLS NEEDED

Wire cutter

⚠ WARNING

Exceeding the product rating can cause loss of warranty, overheating and potential fire. Do not exceed product rating or tow vehicle lamp load rating, whichever is lower.

Signal Circuits - 7.5 amps per side
Tail / Running Circuits - 7.5 amps total

Check vehicle owner's manual or contact the vehicle manufacturer for more information.

INSTALLATION / SAFETY INSTRUCTIONS

Step 1

Locate vehicle battery on the driver side under the hood and disconnect the negative battery terminal.

Step 2

Locate the vehicle connector behind the rear bumper in the center of the vehicle. The connector will be similar to that on the CURT wiring connector (A).

Step 3

Separate the vehicle connectors from the weather seal connectors. Take care not to damage the locking tabs.

Step 4

Insert the CURT wiring connector end into the vehicle connector. Make sure the connectors are fully inserted with locking tabs in place.

Step 5

When in use, route the 4-flat to the center of the vehicle. When not in use, roll up and store in a convenient, out of the way location. Secure any loose wires with the provided cable ties.

Step 6

Reinstall all items removed during install and reconnect negative battery terminal. Install the provided 4-flat dust cover to help prevent corrosion.

